

COFFEE GRINDS PARTICLE SIZE DISTRIBUTION


Please print this page at full size/no borders. The distance between the **inside** of the markers should be **100mm**. Only particles fully within the inside corners of the markers will be analyzed.

Our current methodology is to evaluate the aggregate of four different images for each specific sample. (The tool can automatically generate the aggregate histogram/statistics.)

Try to have direct, soft lighting that's even, without big shadows, etc. Best results have been obtained by scattering small amounts of ground coffee within each square, using a small measuring spoon to get a wide sample from the dosing cup.

It's important to have as little clumping or overlap as possible. The software has several mechanisms to break overlapping particles up, but it's still in progress. I've used a WDT tool to manually break up clumps.

It's also important that the images you load into the tool only have **four** markers showing to make sure the template is accurately recognized. **/mgsecure**



COFFEE GRINDS PARTICLE SIZE DISTRIBUTION

Please print this page at full size/no borders. The distances between the **inside** of the markers should be 75mm and 50mm. Particles fully within the inside corners of the markers will be analyzed. These alternate templates can be used for close-ups of samples that are very coarse (75mm) or to get a closer analysis of finer grinds (50mm).

It's important that the images you load into the tool only have **four** markers showing to make sure the template is accurately recognized.

